

P8/P9 Cable Assembly Kit



(Qty 2) Aluminum Backshell Body P8/P9 (MEC-28M-01-301-02)

(Qty 1) MDM 25-pin Female Connector (CONN-380-025-213L001)

(Qty 2) Knurled 2-56 Thumbscrews (NTEC-B71014305)

(Qty 4) 5/16-inch 0-80 Flat-head Philips Screws, Stainless Steel

(Qty 1) PCB Board P8/P9 Assembly (HARM-3428M0138901)

Notes:

- 1.) See page 2 for PCB details
- 2.) See page 3 for assembly instructions.

Lumistar Inc. 2270 Camino Vida Roble, Suite L Carlsbad, CA 92011 (760) 431-2181		
Title: LS-28M P8/P9 Cable Assembly Kit		
Size A	Document Number: CBL-28M-01-K89-01	REV -
Date: 01/05/19		Sheet 1 of 3

P8/P9 PCB Detail




Table 1. P8/P9 Connector Pinout


P8/P9 Connector Pin	PCB Pad Identifier
1	E1
2	E2
3	E3
4	E4
5	E5
6	E6
7	E7
8	E8
9	E9
10	E10
11	E11
12	E12
13	E13
20	E20
21	E21
23	E23
24	E24
14-19, 22	Ground

Notes:

- 1.) See Table 1 for MDM pin versus E-pad designations.

Lumistar Inc. 2270 Camino Vida Roble, Suite L Carlsbad, CA 92011 (760) 431-2181		
Title: LS-28M P8/P9 Cable Assembly Kit		
Size A	Document Number: CBL-28M-01-K89-01	REV -
Date: 01/05/19		Sheet 2 of 3

Assembly Instructions



(Picture above is provided as an example for various cable connection types and may not reflect the actual PCB of this specific kit)

Assembly Procedure:

- 1.) Solder MDM connector in an end-launch fashion to the bare PCB assembly.
- 2.) Attach cables to PCB assembly as desired. Terminate shields to the common ground strap on either side of the PCB assembly.
- 3.) Insert MDM-PCB-Cable assembly into one backshell cover.
- 4.) Insert thumbscrews as shown.
- 5.) Apply the opposing back shell half.
- 6.) Use four 0-80 screws, two on each side of the backshell assembly to secure the covers.

Notes:

- 1.) Lumistar recommends the use of RG174 50-ohm Shielded cable for single-ended connections
- 2.) Lumistar recommends the use of Tyco Raychem 55A1121-26-6/9-9 110-ohm Twisted Shielded Pair cabling for differential signals.

Lumistar Inc. 2270 Camino Vida Roble, Suite L Carlsbad, CA 92011 (760) 431-2181		
Title: LS-28M P8/P9 Cable Assembly Kit		
Size A	Document Number: CBL-28M-01-K89-01	REV -
Date: 01/05/19		Sheet 3 of 3